




# Assembly Instructions - Ikon Delta Edge Office Shelving



NOTE: NUTS & BOLTS MAY BE SUBSTITUTED IN LIEU OF PLASTIC DRIVE RIVETS.

## STARTER BAY

Note: Delta edge = front, T section = rear

1. Stand 1 x end panel upright and insert 2 x shelf clips at the same level (just above mid-height).
2. Insert 2 x shelf clips in the 2<sup>nd</sup> panel to match the first.
3. Insert a shelf by locating it onto the installed shelf clips (2 person assembly recommended) – unit should now be free-standing with support by one person.
4. Insert clips at top and bottom slots on both panels, then insert 2 more shelves.
5. Take one of the back sheets and line it up with the top holes whilst another person inserts the plastic drive fasteners (or nuts and bolts if supplied). The sheets are installed inside the 'T', fasteners go in from the front.
6. Install the lower back sheet and H joint section below the top panel, secure in place as before.

7. Place the remaining shelves in the required position, the first shelf may need to be adjusted from its original position. Make sure the back sheets are the correct way up (see diagram above).

## ADD-ON BAY

1. Position a sidewall, a shelf width away from the end of a starter bay and position clips top and bottom, level with the clips that are in the initial bay.
2. Position the top and bottom shelves onto the clips in both sidewalls.
3. Repeat stages 5 & 6 to attach the back sheets, then place the remaining shelves in the required position.

### Safety Note:

Due to the height to depth ratio, these units should always be fixed back to a wall.